

Analog Controller A Header Pins
Upper Drawbars
1 - Drawbar 16
2 - Drawbar 5 1/3
3 - Drawbar 8
4 - Drawbar 4
5 - Drawbar 2 2/3
6 - Drawbar 2
7 - Drawbar 1 5/9
8 - Drawbar 1 1/3
9 - Drawbar 1
...

12 - (VibKnob Analog R-Switch)
13, 14 - Drawbar Gnd
15, 16 - Drawbar V+ (Reference)

Analog Controller B Header Pins
Lower and Bass Drawbars
1 - Drawbar 16
2 - Drawbar 5 1/3
3 - Drawbar 8
4 - Drawbar 4
5 - Drawbar 2 2/3
6 - Drawbar 2
7 - Drawbar 1 5/9
8 - Drawbar 1 1/3
9 - Drawbar 1
10 - Drawbar Bass 16
11 - Drawbar Bass 8
12 - Drawbar/Pot Bass Sustain
13, 14 - Drawbar Gnd
15, 16 - Drawbar V+ (Reference)